

## **Instructions to install remote control software on plankton board**

1. Download the remote-control software from the below link provided by AAEON into a USB thumb drive.
2. Plug the USB thumb drive which has remote-control software to the AAEON board.
3. Issue the following commands on a terminal Console:
  - I. `sudo mount /dev/sda1 /media/usb`
  - II. `cd /media/usb`
  - III. `sudo dpkg -i ConnectWiseControl.ClientSetup.deb`