AVend Local Dispense API Guide

Table of Contents

Revisions	2
Overview	3
Prerequisites	3
API	4
Syntax	4
API Calls	5
Examples	6
Notes	6

Revisions

Version	Date	Changes
V1.1.0	2020.10	Initial public release
V1.1.5	2021.04	Added Port option in the API Endpoint specs.
V1.2.0	2023.10	Included mode setting
V1.2.1	2023.11	Included HTML URL Encoding
V1.2.2	2024.01	Added Info call

Overview

AVend Local Dispense API ("API") provides an easy way to effect physical dispense of supported vending machines. This enables software-control dispense and opens up numerous new possibilities and use cases for vending machines.

The API is a based on the HTTP REST model. It provides Cart functionality for multiple-item dispense ("Multi-Vend")¹. It supports Session concept for robust operation.

Prerequisites

An AVend SmatVending kit ("AVend kit") is properly integrated with the target vending machine.

The AVend API middleware ("middleware") installed on the AVend kit establishes an API host with an endpoint for the API calls.

To use the API it is assumed that proper network setup is done and the calling app is able to reach the API endpoint provided by the middleware.

API

Syntax

API Endpoint/?action=v1&code=v2&mode=v3

Where:

API_Endpoint has the format of "http://host[:portnum]/avend", where the host is the IP or hostname where AVend API middleware is installed; the default TCP port is 8080.

action is a required keyword, and v1 is one of the following values:
 (start | dispense | add | remove | clear | info);

code is required when the action keyword is "add" or "remove"; it is optional when the action is "dispense"; Its v2 is a number or character representing the keypress on the keypad. For symbolic symbols such as * or # consider using their HTML URL Encoding. (e.g. %23 instead of # and %2A instead of *)

mode is optional and only applies when the action is "dispense"

Its *v3* is either single or double where double will pad the code provided with an extra 0 up to two digits. This is the default behavior if mode is not specified. single will not perform this padding.

portnum is required when the endpoint is installed at a specific TCP port **portnum**. The [:portnum] can be omitted if the API endpoint is set up using http default port 80.

Note that some OSes by default block port 80. In those cases, a specific TCP port will need to be specified.

API Calls

API Call	Description
http://host:8080/avend?action=start	Start a session to begin transaction. All other API calls will have no effect unless a session has started. Inactive session timeouts in 5 minutes.
http://host:8080/avend?action=dispense&code=v2	Dispense selection v2 if cart is empty. Otherwise dispense the item(s) in cart.
http://host:8080/avend?action=dispense& code=v2&mode=single	Dispense selection v2 if the cart is empty. Otherwise dispense the item(s) in cart but as a single keypress if v2 is a single digit.
http://host:8080/avend?action=add&code=v2	Add selection v2 to Cart.
http://host:8080/avend?action=dispense	Dispense item(s) in Cart.
http://host:8080/avend?action=remove&code=v2	Remove selection v2 from Cart.
http://host:8080/avend?action=clear	Clear Cart.
http://host:8080/avend?action=info	Returns info about the current configuration.

Table 1

Note: Swap "host" in the API Calls documented in Table 1 with the API host IP (or hostname if defined and reachable in the network).

Examples

The following examples assume AVend middleware is running at IP 127.0.0.1.

Single-Vend API calls

```
Start – http://127.0.0.1:8080/avend?action=start

Dispense – http://127.0.0.1:8080/avend?action=dispense&code=37
```

What physically happens

Product at selection 37 is dispensed

Multi-Vend API calls¹

```
Start – http://127.0.0.1:8080/avend?action=start

Add 05 selection to Cart –

http://127.0.0.1:8080/avend?action=add&code=24
```

Add 01 selection to Cart-

http://127.0.0.1:8080/avend?action=add&code=05

Dispense – http://127.0.0.1:8080/avend?action=dispense

What physically happens

Product at selection 24 is dispensed Product at selection 05 is dispensed.

Notes

1. Multi-Vend function requires vend-status integration between the AVend kit and the target vending machine.